



Washroom/ Personal Hygiene



Wet Floor Cleaning



Exterior Cleaning

No.	Prod. No.	Description	No.	Prod. No.	Description
29	40152	L-Tipped Fryer Brush	42	40146	Floor Drain Brush
30	40159	Dishwasher Machine Brush	43	40005	Multi-Purpose Brush
31	40028	Dishwasher Spray Arm Brush	44	40111	L-Tipped Fryer Brush
32	40024	Bake Pan Lip Brush	45	40006	Multi-Purpose Brush
33	40001	Ice Cream Freezer Brush	46	40541	Spectrum® Utility Scrub Brush
34	40413	Dish Wash Brush	47	40735	Brush Rack
35	40423	Hi-Lo™ Floor Brush (40285 Handle)	48	40401	Meteor® Pastry Brush
36	40671	Wire Scratch Brush w/Scraper	49	40115	Waffle Iron Buttering Brush
37	40480	Counter Top Brush	50	40114	Waffle Iron Cleaning Brush
38	40481	Counter Top Brush	51	40020	Hand & Nail Brush
39	40290	Broiler Master Grill Brush	52	36190	Hi-Lo™ Floor Brush w/Squeegee
40	40430	All-Around™ Floor Brush	53	40140	Bowl Brush
41	40377	Chef Series™ Croissant Brush	54	41568	Spectrum® Hygenic Squeegee
			55	41881	Omni Sweep™

